

Best Skin Ever General Application Instructions.

Please read all of the instructions before you begin. If you have any questions, do not hesitate to contact us at info@bestskinsever.com.

To see these same instructions with pictures click the Order Status link on our web site to find the Application Instructions page.

Please note: A small amount of water is required to apply your BSE and its application could possibly void the warranty of your device. The liability of Best Skins Ever does not extend beyond our products

Suggestions before you begin...

DO NOT APPLY WATER DIRECTLY TO YOUR DEVICE!!!! We can't stress this enough.

If the Skin you purchased came with multiple pieces apply the front skin to your device first. This way the front is protected when you turn it over to apply the rear skin.

You can perform the entire application in a steamy bathroom to reduce dust trapping under the skin during application.

1. TURN YOUR DEVICE OFF AND ENGAGE THE HOLD SWITCH!!!! Take the battery out if it is removable!

2. Wash your hands and clean any fingerprints from your device. Next, in a spray bottle, mix about 1/4 teaspoon of mild liquid soap with about 10 oz. water to make the application solution. Baby shampoo or liquid dish soap work best. Stay away from soaps with additives such as creamy hand soaps.

3. Identify the function pieces of the Skin and determine what parts of the device they are applied to

Tip: Keeping your finger tips wet with solution will prevent your fingers from sticking to the adhesive and leaving finger prints on the under side of the skin.

4. Spray your fingers with the solution and peel the skin from the liner. Spray the adhesive side thoroughly as you peel it from the liner. Do not lose track of which side of the Skin was stuck to the liner! This is the side that will adhere to the device.

Note: If you don't have a spray bottle you can simply mix the solution in a shallow dish and dip the Skin into the solution.

Tip: We highly suggest using a spray bottle when applying large pieces such as laptop Skins. It helps to have an extra hand with the large pieces to spray the Skin as you peel it from the liner. The solution will prevent the Skin from folding over and sticking to itself once it's removed from the liner.

5. Lightly shake excess water from the Skin. It doesn't need to be dripping wet; a thin film of solution works the best.

6. Slowly lay the Skin onto the device and slide it into position. The Skin should slide freely on the surface of your device at this point. If it doesn't try adding a little more soap to your water and re-wetting the film.

7. Begin by pressing some of the water out from under the film with your fingers being careful not to move the Skin from its place.

8. Use a credit card (or something similar) to squeegee the remainder of water and bubbles out from under the film.

****If you see bubbles you are unable to remove or are unhappy with the placement of your Skin, now is the time to remove it and return to step 1. After it has time to set up you will not be able to remove the Skin without stretching it.**

9. If you are applying a skin with flaps, corners or areas that won't stick down, give the Skin about 15-30 minutes for the solution to evaporate. Then wrap the area over and press it down with your thumb or palm of your hand for about 30 seconds.

Note: It's important to understand the adhesive is not water-soluble. Adding more solution to areas that are having trouble adhering will only prolong the issue.

10. After pressing down the last area, we suggest that you let the Skin set up for 24 hours before turning on the device. **The look of your BSE will improve over the next 24-48 hours as the water and small bubbles dissipate and the adhesive sets up.**

Tip: Take the time to store your extra Skins in the envelope or a zip lock bag. **Do Not store any unused skins face to face.** They will stick together.

Removal: When you're ready to remove the Skin you can simply peel it off. For best results peel slowly and don't peel the Skin back over itself. Peel the Skin away from itself at an angle of 45 degrees or less.

We're always looking for ways to improve our product. If you have any suggestions, please let us hear about them at info@bestskinsever.com

If you're happy with your BSE please share our Web site with your friends on your favorite message board.